

```

1  /**
2  *
3  *  @copyright &copy; 2010 - 2020, Fraunhofer-Gesellschaft zur Foerderung der
4  *  angewandten Forschung e.V. All rights reserved.
5  *
6  *  BSD 3-Clause License
7  *  Redistribution and use in source and binary forms, with or without
8  *  modification, are permitted provided that the following conditions are met:
9  *  1. Redistributions of source code must retain the above copyright notice,
10 *  this list of conditions and the following disclaimer.
11 *  2. Redistributions in binary form must reproduce the above copyright
12 *  notice, this list of conditions and the following disclaimer in the
13 *  documentation and/or other materials provided with the distribution.
14 *  3. Neither the name of the copyright holder nor the names of its
15 *  contributors may be used to endorse or promote products derived from
16 *  this software without specific prior written permission.
17 *
18 *  THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS"
19 *  AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
20 *  IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
21 *  ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE
22 *  LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
23 *  CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
24 *  SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
25 *  INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN
26 *  CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)
27 *  ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE
28 *  POSSIBILITY OF SUCH DAMAGE.
29 *
30 *  We kindly request you to use one or more of the following phrases to refer
31 *  to foxBMS in your hardware, software, documentation or advertising
32 *  materials:
33 *
34 *  &Prime;This product uses parts of foxBMS&reg;&Prime;;
35 *
36 *  &Prime;This product includes parts of foxBMS&reg;&Prime;;
37 *
38 *  &Prime;This product is derived from foxBMS&reg;&Prime;;
39 *
40 */
41
42 /**
43 *  @file    can_cfg.c
44 *  @author  foxBMS Team
45 *  @date    12.07.2015 (date of creation)
46 *  @ingroup DRIVERS_CONF
47 *  @prefix  CAN
48 *
49 *  @brief   Configuration for the CAN module
50 *
51 *  The CAN bus settings and the received messages and their
52 *  reception handling are to be specified here.

```

```

53  *
54  */
55
56  /*===== Includes =====*/
57  #include "can_cfg.h"
58
59  #include "batteryssystem_cfg.h"
60  #include "mcu.h"
61  #include "rcc_cfg.h"
62
63  /*===== Macros and Definitions =====*/
64
65  /*===== Constant and Variable Definitions =====*/
66
67  /*===== Function Prototypes =====*/
68
69  /*===== Function Implementations =====*/
70
71  /* *****
72   * Set CAN settings here
73   *****/
74
75  CAN_HandleTypeDef hcan0 = {
76      .Instance = CAN2,
77      .State = HAL_CAN_STATE_RESET,
78      .ErrorCode = HAL_CAN_ERROR_NONE,
79  #if (CAN0_BAUDRATE == 1000000)
80  #if (RCC_APB1_CLOCK == 45000000)
81      .Init.Prescaler = 3,          /* CAN_CLOCK = APB1 = 45MHz */
82                                  /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
83                                  /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
84      .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 45MHz/3/15 = 1.0MHz */
85      .Init.TimeSeg2 = CAN_BS2_8TQ,
86  #elif (RCC_APB1_CLOCK == 42000000)
87      .Init.Prescaler = 3,          /* CAN_CLOCK = APB1 = 42MHz */
88                                  /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
89                                  /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
90      .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 42MHz/3/14 = 1.0MHz */
91      .Init.TimeSeg2 = CAN_BS2_7TQ,
92  #elif (RCC_APB1_CLOCK == 32000000)
93      .Init.Prescaler = 4,          /* CAN_CLOCK = APB1 = 32MHz */
94                                  /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
95                                  /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
96      .Init.TimeSeg1 = CAN_BS1_5TQ, /* --> CAN = 32MHz/4/8 = 1.0MHz */
97      .Init.TimeSeg2 = CAN_BS2_2TQ,
98  #else
99  #error "Please configure CAN Baudrate according to your clock configuration "
100 #endif
101 #elif (CAN0_BAUDRATE == 500000)
102 #if (RCC_APB1_CLOCK == 45000000)
103     .Init.Prescaler = 6,          /* CAN_CLOCK = APB1 = 45MHz */
104                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */

```

```

105                                     /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
106         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 45MHz/6/15 = 0.5MHz */
107         .Init.TimeSeg2 = CAN_BS2_8TQ,
108 #elif(RCC_APB1_CLOCK == 42000000)
109         .Init.Prescaler = 6,                /* CAN_CLOCK = APB1 = 42MHz */
110                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
111                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
112         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 42MHz/6/14 = 0.5MHz */
113         .Init.TimeSeg2 = CAN_BS2_7TQ,
114 #elif RCC_APB1_CLOCK == 32000000
115         .Init.Prescaler = 8,                /* CAN_CLOCK = APB1 = 32MHz */
116                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
117                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
118         .Init.TimeSeg1 = CAN_BS1_5TQ,      /* --> CAN = 32MHz/8/8 = 0.5MHz */
119         .Init.TimeSeg2 = CAN_BS2_2TQ,
120 #else
121 #error "Please configure CAN Baudrate according to your clock configuration "
122 #endif
123 #elif(CAN0_BAUDRATE == 250000)
124 #if (RCC_APB1_CLOCK == 45000000)
125         .Init.Prescaler = 12,               /* CAN_CLOCK = APB1 = 45MHz */
126                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
127                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
128         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 45MHz/12/15 = 0.25MHz */
129         .Init.TimeSeg2 = CAN_BS2_8TQ,
130 #elif(RCC_APB1_CLOCK == 42000000)
131         .Init.Prescaler = 12,               /* CAN_CLOCK = APB1 = 42MHz */
132                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
133                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
134         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 42MHz/12/14 = 0.25MHz */
135         .Init.TimeSeg2 = CAN_BS2_7TQ,
136 #elif RCC_APB1_CLOCK == 32000000
137         .Init.Prescaler = 16,               /* CAN_CLOCK = APB1 = 32MHz */
138                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
139                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
140         .Init.TimeSeg1 = CAN_BS1_2TQ,      /* --> CAN = 32MHz/16/8 = 0.25MHz */
141         .Init.TimeSeg2 = CAN_BS2_5TQ,
142 #else
143 #error "Please configure CAN Baudrate according to your clock configuration "
144 #endif
145 #elif(CAN0_BAUDRATE == 125000)
146 #if (RCC_APB1_CLOCK == 45000000)
147         .Init.Prescaler = 24,               /* CAN_CLOCK = APB1 = 45MHz */
148                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
149                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
150         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 45MHz/12/14 = 0.125MHz */
151         .Init.TimeSeg2 = CAN_BS2_8TQ,
152 #elif(RCC_APB1_CLOCK == 42000000)
153         .Init.Prescaler = 24,               /* CAN_CLOCK = APB1 = 42MHz */
154                                             /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
155                                             /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
156         .Init.TimeSeg1 = CAN_BS1_6TQ,      /* --> CAN = 42MHz/12/14 = 0.125MHz */

```

```

157     .Init.TimeSeg2 = CAN_BS2_7TQ,
158 #elif RCC_APB1_CLOCK == 32000000
159     .Init.Prescaler = 32,          /* CAN_CLOCK = APB1 = 32MHz */
160                                     /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
161                                     /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
162     .Init.TimeSeg1 = CAN_BS1_2TQ,  /* --> CAN = 32MHz/16/8 = 0.125MHz */
163     .Init.TimeSeg2 = CAN_BS2_5TQ,
164 #else
165 #error "Please configure CAN Baudrate according to your clock configuration "
166 #endif
167 #endif
168 .Init.Mode = CAN_MODE_NORMAL, /* for test purpose, without connected can-bus use LOOPBACK mode */
169 .Init.SyncJumpWidth = CAN_SJW_1TQ,
170 .Init.TimeTriggeredMode = DISABLE, /* time triggerd communication mode */
171                                     /* DISABLE: no influence */
172                                     /* ENABLE: saves timestamps for received and transmitted messages. See reference manual
173                                     for more information. */
174                                     /* DISABLE: Manually re-initialize CAN and wait for 128 * 11 recessive bits */
175 .Init.AutoBusOff = ENABLE, /* automatic bus-off management */
176                                     /* ENABLE: automatically leave bus-off mode after 128 * 11 recessive bits */
177 .Init.AutoWakeUp = ENABLE, /* automatic wake-up mode */
178                                     /* ENABLE: automatically leave sleep mode on message receiving */
179                                     /* DISABLE: SLEEP bit needs to be deleted by software */
180 .Init.AutoRetransmission = DISABLE, /* automatic retransmission mode; */
181                                     /* DISABLE: retransmit the message until it has been successfully transmitted */
182                                     /* ENABLE: transmit only once, independently of transmission result */
183 .Init.ReceiveFifoLocked = ENABLE, /* Receive FIFO locked against overrun. */
184                                     /* DISABLE: A new incoming message overwrites the last received message. */
185                                     /* ENABLE: Once a receive FIFO is full the next incoming message will be discarded. */
186 .Init.TransmitFifoPriority = ENABLE, /* Transmit FIFO priority */
187                                     /* DISABLE: driven by identifier of message. Lower identifier equals higher priority */
188                                     /* ENABLE: driven chronologically */
189 };
190
191
192 CAN_HandleTypeDef hcan1 = {
193     .Instance = CAN1,
194     .State = HAL_CAN_STATE_RESET,
195     .ErrorCode = HAL_CAN_ERROR_NONE,
196 #if (CAN1_BAUDRATE == 1000000)
197 #if (RCC_APB1_CLOCK == 45000000)
198     .Init.Prescaler = 3,          /* CAN_CLOCK = APB1 = 45MHz */
199                                     /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
200                                     /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
201     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 45MHz/3/15 = 1.0MHz */
202     .Init.TimeSeg2 = CAN_BS2_8TQ,
203 #elif (RCC_APB1_CLOCK == 42000000)
204     .Init.Prescaler = 3,          /* CAN_CLOCK = APB1 = 42MHz */
205                                     /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
206                                     /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
207     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 42MHz/3/14 = 1.0MHz */

```

```

208     .Init.TimeSeg2 = CAN_BS2_7TQ,
209 #elif RCC_APB1_CLOCK == 32000000
210     .Init.Prescaler = 4,          /* CAN_CLOCK = APB1 = 32MHz */
211                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
212                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
213     .Init.TimeSeg1 = CAN_BS1_5TQ, /* --> CAN = 32MHz/4/8 = 1.0MHz */
214     .Init.TimeSeg2 = CAN_BS2_2TQ,
215 #else
216 #error "Please configure CAN Baudrate according to your clock configuration "
217 #endif
218 #elif(CAN1_BAUDRATE == 500000)
219 #if (RCC_APB1_CLOCK == 45000000)
220     .Init.Prescaler = 6,          /* CAN_CLOCK = APB1 = 45MHz */
221                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
222                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
223     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 45MHz/6/15 = 0.5MHz */
224     .Init.TimeSeg2 = CAN_BS2_8TQ,
225 #elif(RCC_APB1_CLOCK == 42000000)
226     .Init.Prescaler = 6,          /* CAN_CLOCK = APB1 = 42MHz */
227                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
228                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
229     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 42MHz/6/14 = 0.5MHz */
230     .Init.TimeSeg2 = CAN_BS2_7TQ,
231 #elif RCC_APB1_CLOCK == 32000000
232     .Init.Prescaler = 8,          /* CAN_CLOCK = APB1 = 32MHz */
233                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
234                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
235     .Init.TimeSeg1 = CAN_BS1_5TQ, /* --> CAN = 32MHz/8/8 = 0.5MHz */
236     .Init.TimeSeg2 = CAN_BS2_2TQ,
237 #else
238 #error "Please configure CAN Baudrate according to your clock configuration "
239 #endif
240 #elif(CAN1_BAUDRATE == 250000)
241 #if (RCC_APB1_CLOCK == 45000000)
242     .Init.Prescaler = 12,         /* CAN_CLOCK = APB1 = 45MHz */
243                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
244                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
245     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 45MHz/12/15 = 0.25MHz */
246     .Init.TimeSeg2 = CAN_BS2_8TQ,
247 #elif(RCC_APB1_CLOCK == 42000000)
248     .Init.Prescaler = 12,         /* CAN_CLOCK = APB1 = 42MHz */
249                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
250                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
251     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 42MHz/12/14 = 0.25MHz */
252     .Init.TimeSeg2 = CAN_BS2_7TQ,
253 #elif RCC_APB1_CLOCK == 32000000
254     .Init.Prescaler = 16,         /* CAN_CLOCK = APB1 = 32MHz */
255                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
256                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
257     .Init.TimeSeg1 = CAN_BS1_5TQ, /* --> CAN = 32MHz/16/8 = 0.25MHz */
258     .Init.TimeSeg2 = CAN_BS2_2TQ,
259 #else

```

```

260 #error "Please configure CAN Baudrate according to your clock configuration "
261 #endif
262 #elif(CAN1_BAUDRATE == 125000)
263 #if (RCC_APB1_CLOCK == 45000000)
264     .Init.Prescaler = 24,          /* CAN_CLOCK = APB1 = 45MHz */
265                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
266                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
267     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 45MHz/12/14 = 0.125MHz */
268     .Init.TimeSeg2 = CAN_BS2_8TQ,
269 #elif(RCC_APB1_CLOCK == 42000000)
270     .Init.Prescaler = 24,          /* CAN_CLOCK = APB1 = 42MHz */
271                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
272                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
273     .Init.TimeSeg1 = CAN_BS1_6TQ, /* --> CAN = 42MHz/12/14 = 0.125MHz */
274     .Init.TimeSeg2 = CAN_BS2_7TQ,
275 #elif RCC_APB1_CLOCK == 32000000
276     .Init.Prescaler = 32,          /* CAN_CLOCK = APB1 = 32MHz */
277                                   /* resulting CAN speed: APB1/prescaler/sumOfTimequants */
278                                   /* sum: 1tq for sync + TimeSeg1 + TimeSeg2 */
279     .Init.TimeSeg1 = CAN_BS1_5TQ, /* --> CAN = 32MHz/16/8 = 0.125MHz */
280     .Init.TimeSeg2 = CAN_BS2_2TQ,
281 #else
282 #error "Please configure CAN Baudrate according to your clock configuration "
283 #endif
284 #endif
285     .Init.Mode = CAN_MODE_NORMAL, /* for test purpose, without connected can-bus use LOOPBACK mode */
286     .Init.SyncJumpWidth = CAN_SJW_1TQ,
287     .Init.TimeTriggeredMode = DISABLE, /* time triggerd communication mode */
288                                   /* DISABLE: no influence */
289                                   /* ENABLE: saves timestamps for received and transmitted messages. See reference manual
                                   for more information. */
290     .Init.AutoBusOff = ENABLE, /* automatic bus-off management */
291                                   /* DISABLE: Manually re-initialize CAN and wait for 128 * 11 recessive bits */
292                                   /* ENABLE: automatically leave bus-off mode after 128 * 11 recessive bits */
293     .Init.AutoWakeUp = ENABLE, /* automatic wake-up mode */
294                                   /* ENABLE: automatically leave sleep mode on message receiving */
295                                   /* DISABLE: SLEEP bit needs to be deleted by software */
296     .Init.AutoRetransmission = DISABLE, /* automatic retransition mode; */
297                                   /* DISABLE: retransmit the message until it has been successfully transmitted */
298                                   /* ENABLE: transmit only once, independently of transmission result */
299     .Init.ReceiveFifoLocked = ENABLE, /* Receive FIFO locked against overrun. */
300                                   /* DISABLE: A new incoming message overwrites the last received message. */
301                                   /* ENABLE: Once a receive FIFO is full the next incoming message will be discarded. */
302     .Init.TransmitFifoPriority = ENABLE, /* Transmit FIFO priority */
303                                   /* DISABLE: driven by identifier of message. Lower identifier equals higher priority */
304                                   /* ENABLE: driven chronologically */
305 };
306
307
308
309 /* *****
310  * Configure TX messages here

```

```

311 *****/
312
313 const CAN_MSG_TX_TYPE_s can_CAN0_messages_tx[] = {
314     { 0x110, 8, 100, 0, NULL_PTR }, /*!< BMS system state 0 */
315     { 0x111, 8, 100, 0, NULL_PTR }, /*!< BMS system state 1 */
316     { 0x112, 8, 100, 0, NULL_PTR }, /*!< BMS system state 2 */
317
318     { 0x115, 8, 100, 0, NULL_PTR }, /*!< BMS slave state 0 */
319     { 0x116, 8, 100, 0, NULL_PTR }, /*!< BMS slave state 1 */
320
321     { 0x130, 8, 100, 30, NULL_PTR }, /*!< Maximum allowed cur
322     { 0x131, 8, 100, 30, NULL_PTR }, /*!< SOP */
323     { 0x140, 8, 1000, 30, NULL_PTR }, /*!< SOC */
324     { 0x150, 8, 5000, 30, NULL_PTR }, /*!< SOH */
325     { 0x160, 8, 1000, 30, NULL_PTR }, /*!< SOE */
326     { 0x170, 8, 100, 30, NULL_PTR }, /*!< Cell voltages Min Max Average */
327     { 0x171, 8, 100, 30, NULL_PTR }, /*!< SOV */
328     { 0x180, 8, 100, 30, NULL_PTR }, /*!< Cell temperatures Min Max Average */
329     { 0x190, 8, 1000, 30, NULL_PTR }, /*!< Tempering */
330     { 0x1A0, 8, 1000, 30, NULL_PTR }, /*!< Insulation */
331
332     { 0x1D0, 8, 1000, 40, NULL_PTR }, /*!< Running average power 0 */
333     { 0x1D1, 8, 1000, 40, NULL_PTR }, /*!< Running average power 1 */
334     { 0x1D2, 8, 1000, 40, NULL_PTR }, /*!< Running average power 2 */
335     { 0x1E0, 8, 1000, 40, NULL_PTR }, /*!< Running average current 0 */
336     { 0x1E1, 8, 1000, 40, NULL_PTR }, /*!< Running average current 1 */
337     { 0x1E2, 8, 1000, 40, NULL_PTR }, /*!< Running average current 2 */
338
339     { 0x1F0, 8, 1000, 40, NULL_PTR }, /*!< Pack voltage */
340
341     { 0x200, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 0 1 2 */
342     { 0x201, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 3 4 5 */
343     { 0x202, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 6 7 8 */
344     { 0x203, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 9 10 11 */
345     { 0x204, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 12 13 14 */
346     { 0x205, 8, 200, 20, NULL_PTR }, /*!< Cell voltages module 0 cells 15 16 17 */
347
348     { 0x210, 8, 200, 30, NULL_PTR }, /*!< Cell temperatures module 0 cells 0 1 2 */
349     { 0x211, 8, 200, 30, NULL_PTR }, /*!< Cell temperatures module 0 cells 3 4 5 */
350     { 0x212, 8, 200, 30, NULL_PTR }, /*!< Cell temperatures module 0 cells 6 7 8 */
351     { 0x213, 8, 200, 30, NULL_PTR }, /*!< Cell temperatures module 0 cells 9 10 11 */
352
353     { 0x220, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 0 1 2 */
354     { 0x221, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 3 4 5 */
355     { 0x222, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 6 7 8 */
356     { 0x223, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 9 10 11 */
357     { 0x224, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 12 13 14 */
358     { 0x225, 8, 200, 40, NULL_PTR }, /*!< Cell voltages module 1 cells 15 16 17 */
359
360     { 0x230, 8, 200, 50, NULL_PTR }, /*!< Cell temperatures module 1 cells 0 1 2 */
361     { 0x231, 8, 200, 50, NULL_PTR }, /*!< Cell temperatures module 1 cells 3 4 5 */
362     { 0x232, 8, 200, 50, NULL_PTR }, /*!< Cell temperatures module 1 cells 6 7 8 */

```



The message ID we need to change

```
363 { 0x233, 8, 200, 50, NULL_PTR }, /*!< Cell temperatures module 1 cells 9 10 11 */
364
365 { 0x240, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 0 1 2 */
366 { 0x241, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 3 4 5 */
367 { 0x242, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 6 7 8 */
368 { 0x243, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 9 10 11 */
369 { 0x244, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 12 13 14 */
370 { 0x245, 8, 200, 60, NULL_PTR }, /*!< Cell voltages module 2 cells 15 16 17 */
371
372 { 0x250, 8, 200, 70, NULL_PTR }, /*!< Cell temperatures module 2 cells 0 1 2 */
373 { 0x251, 8, 200, 70, NULL_PTR }, /*!< Cell temperatures module 2 cells 3 4 5 */
374 { 0x252, 8, 200, 70, NULL_PTR }, /*!< Cell temperatures module 2 cells 6 7 8 */
375 { 0x253, 8, 200, 70, NULL_PTR }, /*!< Cell temperatures module 2 cells 9 10 11 */
376
377 { 0x260, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 0 1 2 */
378 { 0x261, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 3 4 5 */
379 { 0x262, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 6 7 8 */
380 { 0x263, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 9 10 11 */
381 { 0x264, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 12 13 14 */
382 { 0x265, 8, 200, 80, NULL_PTR }, /*!< Cell voltages module 3 cells 15 16 17 */
383
384 { 0x270, 8, 200, 90, NULL_PTR }, /*!< Cell temperatures module 3 cells 0 1 2 */
385 { 0x271, 8, 200, 90, NULL_PTR }, /*!< Cell temperatures module 3 cells 3 4 5 */
386 { 0x272, 8, 200, 90, NULL_PTR }, /*!< Cell temperatures module 3 cells 6 7 8 */
387 { 0x273, 8, 200, 90, NULL_PTR }, /*!< Cell temperatures module 3 cells 9 10 11 */
388
389 { 0x280, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 0 1 2 */
390 { 0x281, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 3 4 5 */
391 { 0x282, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 6 7 8 */
392 { 0x283, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 9 10 11 */
393 { 0x284, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 12 13 14 */
394 { 0x285, 8, 200, 100, NULL_PTR }, /*!< Cell voltages module 4 cells 15 16 17 */
395
396 { 0x290, 8, 200, 110, NULL_PTR }, /*!< Cell temperatures module 4 cells 0 1 2 */
397 { 0x291, 8, 200, 110, NULL_PTR }, /*!< Cell temperatures module 4 cells 3 4 5 */
398 { 0x292, 8, 200, 110, NULL_PTR }, /*!< Cell temperatures module 4 cells 6 7 8 */
399 { 0x293, 8, 200, 110, NULL_PTR }, /*!< Cell temperatures module 4 cells 9 10 11 */
400
401 { 0x2A0, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 0 1 2 */
402 { 0x2A1, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 3 4 5 */
403 { 0x2A2, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 6 7 8 */
404 { 0x2A3, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 9 10 11 */
405 { 0x2A4, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 12 13 14 */
406 { 0x2A5, 8, 200, 120, NULL_PTR }, /*!< Cell voltages module 5 cells 15 16 17 */
407
408 { 0x2B0, 8, 200, 130, NULL_PTR }, /*!< Cell temperatures module 5 cells 0 1 2 */
409 { 0x2B1, 8, 200, 130, NULL_PTR }, /*!< Cell temperatures module 5 cells 3 4 5 */
410 { 0x2B2, 8, 200, 130, NULL_PTR }, /*!< Cell temperatures module 5 cells 6 7 8 */
411 { 0x2B3, 8, 200, 130, NULL_PTR }, /*!< Cell temperatures module 5 cells 9 10 11 */
412
413 { 0x2C0, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 0 1 2 */
414 { 0x2C1, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 3 4 5 */
```



```

415 { 0x2C2, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 6 7 8 */
416 { 0x2C3, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 9 10 11 */
417 { 0x2C4, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 12 13 14 */
418 { 0x2C5, 8, 200, 140, NULL_PTR }, /*!< Cell voltages module 6 cells 15 16 17 */
419
420 { 0x2D0, 8, 200, 150, NULL_PTR }, /*!< Cell temperatures module 6 cells 0 1 2 */
421 { 0x2D1, 8, 200, 150, NULL_PTR }, /*!< Cell temperatures module 6 cells 3 4 5 */
422 { 0x2D2, 8, 200, 150, NULL_PTR }, /*!< Cell temperatures module 6 cells 6 7 8 */
423 { 0x2D3, 8, 200, 150, NULL_PTR }, /*!< Cell temperatures module 6 cells 9 10 11 */
424
425 { 0x2E0, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 0 1 2 */
426 { 0x2E1, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 3 4 5 */
427 { 0x2E2, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 6 7 8 */
428 { 0x2E3, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 9 10 11 */
429 { 0x2E4, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 12 13 14 */
430 { 0x2E5, 8, 200, 160, NULL_PTR }, /*!< Cell voltages module 7 cells 15 16 17 */
431
432 { 0x2F0, 8, 200, 170, NULL_PTR }, /*!< Cell temperatures module 7 cells 0 1 2 */
433 { 0x2F1, 8, 200, 170, NULL_PTR }, /*!< Cell temperatures module 7 cells 3 4 5 */
434 { 0x2F2, 8, 200, 170, NULL_PTR }, /*!< Cell temperatures module 7 cells 6 7 8 */
435 { 0x2F3, 8, 200, 170, NULL_PTR }, /*!< Cell temperatures module 7 cells 9 10 11 */
436
437 #ifdef CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED
438     , { 0x35B, 8, 100, 20, NULL_PTR } /*!< Current Sensor Trigger
439 #endif /* CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED */
440 };
441
442
443 const CAN_MSG_TX_TYPE_s can_CAN1_messages_tx[] = {
444 };
445
446 const uint8_t can_CAN0_tx_length = sizeof(can_CAN0_messages_tx)/sizeof(can_CAN0_messages_tx[0]);
447 const uint8_t can_CAN1_tx_length = sizeof(can_CAN1_messages_tx)/sizeof(can_CAN1_messages_tx[0]);
448
449 /* *****
450  * Configure RX messages here
451  * *****
452
453 /* Bypassed messages are --- ALSO --- to be configured here. See further down for bypass ID setting! */
454 CAN_MSG_RX_TYPE_s can0_RxMsgs[] = {
455     { 0x120, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< state request */
456
457     { CAN_ID_SOFTWARE_RESET_MSG, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< software reset */
458
459 #ifdef CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED
460     { 0x35C, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor I */
461     { 0x35D, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor U1 */
462     { 0x35E, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor U2 */
463     { 0x35F, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor U3 */
464     { 0x525, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor T in cyclic mode */
465     { 0x526, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor Power in cyclic mode */
466     { 0x527, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL }, /*!< current sensor C-C in cyclic mode */

```

C cansignal\_cfg.h C cansignal\_cfg.c C can\_cfg.c C can\_cfg.h X C cansignal

mcu-primary > src > driver > config > C can\_cfg.h > CAN\_MSG\_TX\_TYPE\_s

```

297 typedef struct CAN_MSG_RX_TYPE {
298     uint32_t ID; /*!< message ID */
299     uint32_t mask; /*!< mask or 0x0000 to select list mode */
300     uint8_t DLC; /*!< data length */
301     uint8_t RTR; /*!< rtr bit */
302     uint32_t fifo; /*!< selected CAN hardware (CAN_FILTER_FIFO0 or CAN_FILTER_FIFO1) */
303     STD_RETURN_TYPE_e (*func)(uint32_t ID, uint8_t*, uint8_t, uint8_t);
304 } CAN_MSG_RX_TYPE_s;

```

```

467     { 0x528, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor E-C in cyclic mode */
468 #else /* CURRENT_SENSOR_ISABELLENHUETTE_CYCLIC */
469     { 0x521, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor I in cyclic mode */
470     { 0x522, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor U1 in cyclic mode */
471     { 0x523, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor U2 in cyclic mode */
472     { 0x524, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor U3 in cyclic mode */
473     { 0x525, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor T in cyclic mode */
474     { 0x526, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor Power in cyclic mode */
475     { 0x527, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor C-C in cyclic mode */
476     { 0x528, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< current sensor E-C in cyclic mode */
477 #endif /* CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED */
478     { 0x100, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< debug message */
479     { 0x777, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< request SW version */
480     { 0x121, 0xFFFF, 8, 0, CAN_FILTER_FIFO0, NULL },      /*!< engine request */
481 };
482
483
484 CAN_MSG_RX_TYPE_s can1_RxMsgs[] = {
485 };
486
487
488 const uint8_t can_CAN0_rx_length = sizeof(can0_RxMsgs)/sizeof(can0_RxMsgs[0]);
489 const uint8_t can_CAN1_rx_length = sizeof(can1_RxMsgs)/sizeof(can1_RxMsgs[0]);
490
491 /* *****
492  * Set bypass message IDs here
493  *****/
494
495 /* These IDs have to be included in the configuration for the filters in can_RxMsgs[]! */
496 uint32_t can0_bufferBypass_RxMsgs[CAN0_BUFFER_BYPASS_NUMBER_OF_IDS] = { CAN_ID_SOFTWARE_RESET_MSG };
497
498 uint32_t can1_bufferBypass_RxMsgs[CAN1_BUFFER_BYPASS_NUMBER_OF_IDS] = {};
499

```